

TOP SILKSCREEN
TOP COPPER (LAYER 1)
GROUND PLANE (LAYER 2)
MIDDLE COPPER (LAYER 3)
BOTTOM COPPER (LAYER 4)
BOTTOM SILKSCREEN
BOARD OUTLINE

RIGID-FLEX BOARD
4-LAYER 2R-2F
RIGID: LAYERS 1+2
FLEX: LAYERS 3+4

FLEX
FLEX
FLEX
FLEX

